





## ESP-LXD



- 1 Remove jumper wire, if present.**  
*Retire el cable puente, si lo hay.*



- 2 Connect WR2 wires.**  
*Conecte los cables del sensor WR2.*